


MAGNUM MUSTANG



About Us

Magnum Car Panels was founded in 1970 with the object of supplying replacement car body panels to the aftermarket. Since that time the company has developed and manufactured more than eight hundred press tools.

The company takes pride in its ability to provide all customers with a high quality product which is fit for purpose. During design, production, assembly and paint, the relevant departments are subject to a rigorous quality control system thereby ensuring complete satisfaction is achieved by the classic car enthusiast.

With over hundred classic european panel tools and more planned for 2016, all are manufactured using the latest three dimensional computer controlled milling technology. We feel sure we are able to satisfy the demand for classic european body panels throughout Europe, Australasia, Canada and the United States of America.

MAGNUM CAR PANELS LTD

Lawton Street
Rochdale
Lancashire
England
OL12 0LQ

Tel: +44(0)1706 359666
Fax: +44(0)1706 342704
Email: sales@magnumcarpanels.co.uk

www.magnumclassicmustangpanels.co.uk

MAGNUM CAR PANELS

REBUILDING THE CLASSICS

Magnum Classic Car Panels is now on facebook! From Ford, Mini, Mustang and Mercedes, be the first in the know with the latest news and up to date information on new panels in production.



The ultimate classic car builders
facebook page.

Find us on facebook at
www.facebook.com/magnumclassiccpanels

Product List

BATTERY TRAYS

25-75-69-2	Battery Tray 64-66
25-75-69-3	Battery Tray 66-67
25-76-69-0	Battery Tray without Bracket 67-70
25-76-69-2	Battery Tray 67-70
25-79-69-2	Battery Tray with Brackets 71-73
25-76-69-9	J. Bolts for Battery Tray (Pair) W/T Nut 67-70

INNER FRONT WING FULL / SKIN / FRONT / REAR

25-75-38-2	Front Inner Wing (Skin) R/H 65-66
25-75-38-1	Front Inner Wing (Skin) L/H 65-66
25-75-38-10	Front Inner Wing Complete R/H 64-66
25-75-38-9	Front Inner Wing Complete L/H 64-66
25-76-38-10	Front Inner Wing Complete R/H 67-68
25-76-38-9	Front Inner Wing Complete L/H 67-68
25-78-38-4	Rear of Inner Front Wing RHD R/H 67-68
25-75-38-6	Rear Of Inner Front Wing Extension R/H 64-66
25-75-38-5	Rear Of Inner Front Wing Extension L/H 64-66
25-76-38-6	Inner Front Wing Front Section R/H
25-76-38-5	Inner Front Wing Front Section L/H
25-75-38-12	Front Shock Tower Complete R/H 64-66
25-75-38-11	Front Shock Tower Complete L/H 64-66
25-76-38-12	Front Shock Tower Complete R/H 67-68
25-76-38-11	Front Shock Tower Complete L/H 67-68
25-77-38-6	Front Shock Tower Bracket Outer R/H 67-70
25-77-38-5	Front Shock Tower Bracket Outer L/H 67-70
25-78-38-6	Rear Inner Front Wing R/H 69-70
25-78-38-5	Rear Inner Front Wing L/H 69-70
25-75-41-2	Inner Front Wing Front Section R/H 65-66
25-75-41-1	Inner Front Wing Front Section L/H 65-66
25-76-41-2	Inner Front Wing Front Section R/H 67-68
25-76-41-1	Inner Front Wing Front Section L/H 67-68
25-78-41-8	Front Of Inner Front Wing R/H 69-70
25-78-41-7	Front Of Inner Front Wing L/H 69-70

FIREWALL / BULKHEAD FRONT

25-75-38-0	Firewall 64-66
25-76-38-0	Firewall Coupe / Fastback 67-68
25-77-38-1	Firewall 67-68 RHD Only
25-78-38-0	Firewall 69-70

FUEL TANKS

25-75-008	Fuel Tank with Drain Plug 1964-68
25-75-008A	Filler Neck 1964-66
25-75-008B	Filler Neck 1967-68
25-75-008C	Sender Unit 1964-68
25-77-008	Fuel Tank with Drain Plug 69
25-77-008B	Filler Neck 69
25-77-008C	Sender Unit 69

FRONT WINGS

25-75-31-2	Front Wing R/H 65-66
25-75-31-1	Front Wing L/H 65-66
25-76-31-2	Front Wing R/H 67
25-76-31-1	Front Wing L/H 67
25-77-31-2	Front Wing R/H 68
25-77-31-1	Front Wing L/H 68
25-78-31-2	Front Wing R/H 69
25-78-31-1	Front Wing L/H 69
25-79-31-2	Front Wing R/H 70
25-79-31-1	Front Wing L/H 70

BONNETS

25-75-28-0	Bonnet 65-66
25-76-28-0	Bonnet (Turn Signal) 67-68
25-76-28-1	Bonnet Standard 67-68
25-78-28-0	Bonnet Standard 69-70
25-75-38-202	Hinge R/H 65-66
25-75-38-201	Hinge L/H 65-66
25-76-38-202	Hinge R/H 67-70
25-76-38-201	Hinge L/H 67-70
25-79-10-10	Bonnet Latch W/Top Plate 66
25-79-10-11	Bonnet Safety Latch Pin Catch 64-66
25-79-10-12	Bonnet Latch W/Top Plate 64-65
25-79-10-14	Bonnet Latch Assembly 67-68

ENGINE BRACES / MONTE CARLO BARS

25-76-90-11	Monte Carlo Bar Curved In Chrome 65-70
25-76-90-12	Monte Carlo Bar Curved Painted 67-68
25-76-90-13	Export Brace Chrome 65-70
25-76-90-14	Export Brace Painted 65-70
25-76-90-15	Shock Tower Caps (Pair) 65-66
25-76-90-16	Shock Tower Caps (Pair) 67-70

KICK PANELS

25-75-39-2	Kick Panel R/H 64-66
25-75-39-1	Kick Panel L/H 64-66
25-76-39-2	Kick Panel R/H 67-68
25-76-39-1	Kick Panel L/H 67-68

TORQUE BOXES

25-75-38-20	Torque Box Convertible R/H 64-66
25-75-38-19	Torque Box Convertible L/H 64-66
25-76-38-20	Torque Box Coupe/Fastback R/H 67-70
25-76-38-19	Torque Box Coupe/Fastback L/H 67-68
25-76-38-19A	Torque Box Coupe/Fastback L/H 69-70

HEATER BOX

25-76-43-9	Heater Box, Plegnum Chamber with Gasket Kit & Clip 69-70
------------	--

CHASSIS

25-75-38-14	Front Extension Rail Assembly R/H 65-66
25-75-38-13	Front Extension Rail Assembly L/H 65-66
25-75-81-2	Rear Rail Frame Coupe / Fastback R/H 65-68
25-75-81-1	Rear Rail Frame Coupe / Fastback L/H 65-68

FLOORS

25-75-75-4	Half Floor Panel (all models) R/H 64-70
25-75-75-3	Half Floor Panel (all models) L/H 64-70
25-75-75-0	Full Floor Complete Convertible 64-68
25-75-75-1	Full Floor Complete Coupe/Fastback 65-73
25-75-75-7	Front Floor Support 64-66
25-75-75-9	Floor To Firewall Support Convertible (Pair) 65-68
25-77-75-7	Front Floor Support (Pair) 67-68
25-77-75-9	Floor To Firewall Support (Pair) 65-68
25-78-75-9	Floor To Firewall Support (Pair) 69-70

SEAT SUPPORTS

25-75-74-0	Seat Support Platform Convertible 64-70
25-75-74-3	Seat Support Platform Coupe/Fastback 64-70
25-75-76-4	Seat Support Platform R/H 67-68
25-75-76-3	Seat Support Platform L/H 67-68
25-75-76-0	Rear Seat Mount Panel Convertible 64-66
25-78-76-02	Seat Platform R/H 69-70
25-78-76-01	Seat Platform L/H 69-70
25-79-10-8	Seat Track Assembly (PR) 64-68

REAR 1/4 PANELS

25-75-51-2	Rear Quarter Panel Fastback R/H 64-66
25-75-51-1	Rear Quarter Panel Fastback L/H 64-66
25-75-51-4	Rear Quarter Panel Convertible R/H 64-66
25-75-51-3	Rear Quarter Panel Convertible L/H 64-66
25-76-51-2	Rear Quarter Panel Fastback R/H 67
25-76-51-1	Rear Quarter Panel Fastback L/H 67
25-77-51-2	Quarter Panel W/Early Maker Fastback R/H 68
25-77-51-1	Quarter Panel W/Early Maker Fastback L/H 68
25-78-51-02	Quarter Panel F/B R/H 69
25-78-51-01	Quarter Panel F/B L/H 69
25-78-51-2	Rear Quarter Panel R/H Fastback to 70
25-78-51-1	Rear Quarter Panel L/H Fastback to 70

REAR SCUTTLE PANEL

25-75-32-0	Rear Bulkhead/Scuttle Panel Convertible 64-66
25-75-32-1	Rear Bulkhead/Scuttle Panel Fastback 64-66
25-75-32-2	Rear Bulkhead/Scuttle Panel Coupe 65-66
25-76-32-0	Rear Bulkhead/Scuttle Panel Convertible 67-68
25-76-32-1	Rear Bulkhead/Scuttle Panel Coupe 67-68
25-76-32-2	Rear Bulkhead/Scuttle Panel Fastback 67-68
25-77-32-0	Rear Bulkhead/Scuttle Panel Fastback 69-70

ROOF

- 25-75-19-0** Roof Brace Rear Fastback 64-66
25-76-19-1 Roof Drip Rail (PR) Fastback 67-68

DASH

- 25-79-10-13** Dash Pad 69-70
25-79-10-5 Dash Panel Trim R/H 67-68
25-79-10-1 Glove Box Door 67-68

BOOTLID

- 25-75-70-0** Boot Lid Fastback 64-66
25-75-70-2 Boot Lid Coupe/Convertible 64-66
25-76-70-0 Boot Lid Fastback 67-68
25-76-70-1 Boot Lid Coupe/Convertible 67-68
25-78-70-1 Boot Lid Fastback 69-70
25-75-10-14 Boot Lid Hinge Torsion Rods Coupe 67-68

COWL PANEL / UPPER BULKHEAD / SCUTTLE

- 25-75-32-3** Front Bulkhead/Scuttle Complete 64-66
25-76-32-3 Front Bulkhead/Scuttle Grille 67-68
25-76-32-4 Front Bulkhead/Scuttle Complete 67-68
25-78-32-0 Front Bulkhead/Scuttle Complete 69-70

RADIATOR SUPPORT / GRILLE SUPPORT

- 25-75-20-3** Radiator Support 65-66
25-76-20-3 Radiator Support 67-68
25-75-20-6 Radiator Support Bracket Lower R/H 64-66
25-75-20-5 Radiator Support Bracket Lower L/H 64-66
25-76-20-6 Radiator Support Bracket R/H 67-70
25-75-20-5 Radiator Support Bracket L/H 67-70
25-78-20-3 Radiator Support 69
25-79-20-0 Radiator Support Panel 71-75
25-79-20-1 Radiator Support Panel 70
25-76-23-01 Grille Support Lower Bar

REAR FIREWALL / FOLD DOWN SEAT

- 25-75-70-1** Trap Door Behind Rear Seat Fastback 65-66
25-76-30-0 Trap Door Hinge (PR) 65-66
25-76-70-2 Trap Door Behind Rear Seat Fastback 67-68
25-76-70-10 Fold Down Seat Assembly F/B 67-70
25-79-10-9B Fold Down Seat Latch R/H
25-79-10-9A Fold Down Seat Latch L/H
25-79-10-15 Fold Down Seat Moulding Kit Fastback

BOOT INNER

- 25-75-88-0** Boot Floor Complete Convertible 64-66
25-75-88-1 Boot Floor Complete Coupe/Fastback 64-66
25-75-88-6 Boot Drop Off R/H
25-75-88-5 Boot Drop Off L/H
25-75-98-0 Tail Lamp Panel Brace Coupe/Fastback 65-68
25-76-65-8 Transition Panel W/Shock Mount 65-70
25-76-88-0 Boot Floor Complete Convertible 65-70 (No Bumper Brackets)
25-76-88-1 Boot Floor Coupe/Fastback 67-68 (No Bumper Brackets)
25-76-30-1 Boot Lid Prop Assembly

REAR WHEEL HOUSING

- 25-75-55-2** Rear Wheel Housing Complete R/H 64-66
25-75-55-1 Rear Wheel Housing Complete L/H 64-66
25-75-55-4 Rear Wheel Housing Complete Convertible R/H 64-66
25-75-55-3 Rear Wheel Housing Complete Convertible L/H 64-66
25-75-55-6 Inner Rear Wheel Arch Section R/H 64-66
25-75-55-5 Inner Rear Wheel Arch Section L/H 64-66
25-75-55-8 Inner Rear Wheel Housing R/H 64-70
25-75-55-7 Inner Rear Wheel Housing L/H 64-70
25-76-55-2 Rear Wheel Housing Complete R/H 67-68
25-76-55-1 Rear Wheel Housing Complete L/H 67-68
25-76-55-4 Rear Wheel Housing Complete Convertible R/H 67-68
25-76-55-3 Rear Wheel Housing Complete Convertible L/H 67-68
25-76-55-6 Inner Rear Wheel Arch Section R/H 67-68
25-76-55-5 Inner Rear Wheel Arch Section L/H 67-68
25-78-55-4 Rear Wheel House Outer R/H 69-70
25-78-55-3 Rear Wheel House Outer L/H 69-70

REAR PANELS & REAR VALANCES

- 25-75-65-0** Rear Tail Light Panel 65-66
25-76-65-0 Rear Tail Light Panel 67-68
25-76-65-2 Rear Tail Light Panel Shelby 67
25-77-65-0 Rear Tail Light Panel Shelby 68
25-77-65-5 Rear Tail Light Panel 69 (Modify for Shelby)
25-79-65-0 Rear Tail Light Panel 70
25-75-65-10 Boot Corner Panels Fastback R/H 64-66
25-75-65-9 Boot Corner Panels Fastback L/H 64-66
25-75-65-12 Boot Corner Panels Coupe R/H 64-66
25-75-65-11 Boot Corner Panels Coupe L/H 64-66
25-76-65-10 Boot Corner Panels Fastback R/H 67-68
25-76-65-9 Boot Corner Panels Fastback L/H 67-68
25-76-65-12 Boot Corner Panels Coupe R/H 67-68
25-76-65-11 Boot Corner Panels Coupe L/H 67-68
25-75-68-0 Rear Valance (No Reversing Light Hole) 64-66
25-75-68-1 Rear Valance (With Reversing Light Hole) 64-66
25-75-68-2 Rear Valance GT (With Exhaust Holes No Reversing Light Hole) 64-66
25-75-68-3 Rear Valance GT (With Exhaust Holes & Reversing Light Hole) 64-66
25-76-68-0 Rear Valance Standard 67-68
25-76-65-1 Rear Valance W/Dual Exhaust 67-68
25-76-68-1 Rear Valance GT (With Dual Exhaust Hole Cut Outs) 67-68
25-79-68-0 Rear Valance Standard 69-70
25-75-65-5 Rear Light Housing 64-66
25-76-65-5 Rear Lamp Housing 67-68
25-77-98-5 Tail Lamp Bezel 3pc. Set

DOORS - DOOR SKINS & DOOR PILLARS

- 25-75-12-2** Door Shell R/H 64-66
25-75-12-1 Door Shell L/H 64-66
25-76-12-2 Door Shell R/H 67-68
25-76-12-1 Door Shell L/H 67-68
25-78-12-2 Door Shell R/H 69-70
25-78-12-1 Door Shell L/H 69-70
25-75-11-2 Door Skin R/H 65-66
25-75-11-1 Door Skin L/H 65-66
25-76-11-2 Door Skin R/H 67-68
25-76-11-1 Door Skin L/H 67-68
25-76-11-8 Door Window Frame Kit Convertible R/H
25-76-11-7 Door Window Frame Kit Convertible L/H
25-78-11-2 Door Skin R/H 69-70
25-78-11-1 Door Skin L/H 69-70
25-76-11-9 Door Sash Escutcheon Stainless (PR)
25-75-40-2/1 A Pillar (Pair) 64-66
25-76-40-2/1 A Pillar (Pair) 67-68
25-75-40-2A/1A B Pillar (Pair) 64-66
25-76-40-2A/1A B Pillar (Pair) 67-68

FRONT VALANCE

- 25-75-22-0** Front Valance 64-66
25-76-22-0 Front Valance 67-68
25-79-22-0 Front Valance 69
25-79-22-1 Front Valance 70

SILLS & INNER SILLS

- 25-75-00-2** Front Sill Panel R/H 64-68
25-75-00-1 Front Sill Panel L/H 64-68
25-75-00-4 Sill Convertible Complete with Inner Sill Reinforcement R/H 64-68
25-75-00-3 Sill Convertible Complete with Inner Sill Reinforcement L/H 64-68
25-75-00-6 Sill Coupe/Fastback Complete R/H 65-66
25-75-00-5 Sill Coupe/Fastback Complete L/H 65-66
25-75-00-8 Outer Sill R/H 64-66
25-75-00-7 Outer Sill L/H 64-66
25-76-00-2 Sill (Rocker) Complete Coupe/Fastback R/H 67-68
25-76-00-1 Sill (Rocker) Complete Coupe/Fastback L/H 67-68
25-76-00-6 Outer Sill R/H 67-70
25-76-00-5 Outer Sill L/H 67-70
25-76-06-2 Inner Sill Panel R/H 64-70
25-76-06-1 Inner Sill Panel L/H 64-70
25-76-06-4 Inner Sill Convertible R/H 64-68
25-76-06-3 Inner Sill Convertible L/H 64-68

BUMPERS & BUMPER BRACKETS

- 25-75-90-0** Front Bumper 64-66
25-75-95-0 Rear Bumper 64-66
25-76-90-0 Front Bumper 67-68
25-76-95-0 Rear Bumper 67-68
25-78-90-0 Front Bumper 69-70
25-78-95-0 Rear Bumper 69-70
25-75-22-1 Front Bumper Support Filler 64-66
25-76-22-2 Front Bumper Support Filler 67-68
25-75-90-4/3 Front Bumper (Guard) Overider (Pair) 64-66
25-75-95-4/3 Rear Bumper (Guard) Overider (Pair) Painted 64-66
25-75-95-6/5 Rear Bumper (Guard) Overider Bracket (Pair) 65-66
25-75-95-7/8 Rear Bumper (Guard) Overider (Pair) Chrome 64-66
25-76-95-4/3 Rear Bumper (Guard) Overider (Pair) Chrome 67-68
25-76-90-4/3 Front Bumper (Guard) Overider (Pair) Chrome 67-68
25-75-90-8 Front Bumper Bracket from Bumper to Wing R/H 64-66
25-75-90-7 Front Bumper Bracket from Bumper to Wing L/H 64-66
25-75-90-10 Front Bumper Bracket R/H 65-66
25-75-90-9 Front Bumper Bracket L/H 65-66
25-75-90-12 Front Bumper Inner Bracket R/H 65-66
25-75-90-11 Front Bumper Inner Bracket L/H 65-66
25-75-95-9 Rear Bumper Brackets (Pair) 65-66
25-76-90-8 Front Bumper Bracket Inner R/H 67-68
25-76-90-7 Front Bumper Bracket Inner L/H 67-68
25-76-90-10 Front Bumper Bracket Front Outer R/H 67-68
25-76-90-9 Front Bumper Bracket Front Outer L/H 67-68
25-77-90-8 Bumper Bracket Inner Front R/H 69-70
25-77-90-7 Bumper Bracket Inner Front L/H 69-70
25-76-95-7 Rear Bumper Bracket (Pair) 69-70
25-76-95-8 Rear Bumper Brackets (Pair) 67-68
25-75-88-9 Bumper Bracket in Boot (Pair) 65-66
25-76-88-9 Bumper Bracket in Boot (Pair) 67-68
25-77-88-9 Bumper Bracket in Boot (Pair) 69-70
25-79-10-6 Deluxe Bumper Bolt Kit 64-70

MISCELLANEOUS

- 25-79-10-0** Ignition Switch Bracket 67-68
25-79-10-2 Wiper Motor Transmission Arm 66 Only
25-79-10-3 Brake Pedal Automatic 67-68
25-79-10-4 Brake/Clutch Pedal Manual 67-68
25-79-10-7 Front Seats Bottom Spring 65-70

BODYSHELLS TO ORDER (3 MONTH LEAD TIME)

- MS65CV** Body Shell Convertible 65-66
MS65FB Body Shell Fastback 65-66
MS67FB Body Shell Fastback 67-68
MS68FB Body Shell Fastback 68
MS69FB Body Shell Fastback 69
MS70FB Body Shell Fastback 70



MAGNUM MUSTANG - BATTERY TRAYS



25-75-69-2 Battery Tray 64-66



25-75-69-3 Battery Tray 66-67



25-76-69-0 Battery Tray without Bracket 67-70



25-76-69-2 Battery Tray 67-70



25-79-69-2 Battery Tray with Brackets 71-73



25-76-69-9 J. Bolts for Battery Tray (Pair) W/T Nut 67-70

MAGNUM MUSTANG - INNER FRONT WING FULL / SKIN / FRONT / REAR



25-75-38-2 Front Inner Wing (Skin) R/H 65-66

25-75-38-1 Front Inner Wing (Skin) L/H 65-66



25-75-38-10 Front Inner Wing Complete R/H 64-66

25-75-38-9 Front Inner Wing Complete L/H 64-66




25-76-38-10 Front Inner Wing Complete R/H 67-68

25-76-38-9 Front Inner Wing Complete L/H 67-68



25-78-38-4 Rear of Inner Front Wing RHD R/H 67-68



25-75-38-6 Rear Of Inner Front Wing Extension R/H 64-66

25-75-38-5 Rear Of Inner Front Wing Extension L/H 64-66



25-76-38-6 Inner Front Wing Front Section R/H

25-76-38-5 Inner Front Wing Front Section L/H



25-75-38-12 Front Shock Tower Complete R/H 64-66

25-75-38-11 Front Shock Tower Complete L/H 64-66



25-76-38-12 Front Shock Tower Complete R/H 67-68

25-76-38-11 Front Shock Tower Complete L/H 67-68




25-77-38-6 Front Shock Tower Bracket Outer R/H 67-70

25-77-38-5 Front Shock Tower Bracket Outer L/H 67-70



25-78-38-6 Rear Inner Front Wing R/H 69-70

25-78-38-5 Rear Inner Front Wing L/H 69-70



25-75-41-2 Inner Front Wing Front Section R/H 65-66

25-75-41-1 Inner Front Wing Front Section L/H 65-66



25-76-41-2 Inner Front Wing Front Section R/H 67-68

25-76-41-1 Inner Front Wing Front Section L/H 67-68

MAGNUM MUSTANG - INNER FRONT WING FULL /SKIN / FRONT / REAR



25-78-41-8 Front Of Inner Front Wing R/H 69-70

25-78-41-7 Front Of Inner Front Wing L/H 69-70

MAGNUM MUSTANG - FIREWALL / BULKHEAD FRONT



25-75-38-0 Firewall 64-66



25-76-38-0 Firewall Coupe / Fastback 67-68



25-77-38-1 Firewall 67-68 RHD Only



25-78-38-0 Firewall 69-70



25-75-008 Fuel Tank with Drain Plug 1964-68



25-75-008A Filler Neck 1964-66



25-75-008B Filler Neck 1967-68



25-75-008C Sender Unit 1964-68



25-77-008 Fuel Tank with Drain Plug 69

**NO PICTURE
AVAILABLE**

25-77-008B Filler Neck 69



25-77-008C Sender Unit 69

MAGNUM MUSTANG - FRONT WINGS



25-75-31-2 Front Wing R/H 65-66

25-75-31-1 Front Wing L/H 65-66



25-76-31-2 Front Wing R/H 67

25-76-31-1 Front Wing L/H 67



25-77-31-2 Front Wing R/H 68

25-77-31-1 Front Wing L/H 68



25-78-31-2 Front Wing R/H 69

25-78-31-1 Front Wing L/H 69



25-79-31-2 Front Wing R/H 70

25-79-31-1 Front Wing L/H 70

MAGNUM MUSTANG - BONNETS



25-75-28-0 Bonnet 65-66



25-76-28-0 Bonnet (Turn Signal) 67-68



25-76-28-1 Bonnet Standard 67-68



25-78-28-0 Bonnet Standard 69-70



25-75-38-202 Hinge R/H 65-66

25-75-38-201 Hinge L/H 65-66



25-76-38-202 Hinge R/H 67-70

25-76-38-201 Hinge L/H 67-70



25-79-10-10 Bonnet Latch W/Top Plate 66



25-79-10-11 Bonnet Safety Latch Pin Catch 64-66



25-79-10-12 Bonnet Latch W/Top Plate 64-65



25-79-10-14 Bonnet Latch Assembly 67-68



25-76-90-11 Monte Carlo Bar Curved In Chrome 65-70



25-76-90-12 Monte Carlo Bar Curved Painted 67-68



25-76-90-13 Export Brace Chrome 65-70



25-76-90-14 Export Brace Painted 65-70
(3631C & 3631D sold separately)



25-76-90-15 Shock Tower Caps (Pair) 65-66



25-76-90-16 Shock Tower Caps (Pair) 67-70



25-75-39-2 Kick Panel R/H 64-66


25-75-39-1 Kick Panel L/H 64-66



25-76-39-2 Kick Panel R/H 67-68

25-76-39-1 Kick Panel L/H 67-68

MAGNUM MUSTANG - TORQUE BOXES



25-75-38-20 Torque Box Convertible R/H 64-66

25-75-38-19 Torque Box Convertible L/H 64-66



25-76-38-20 Torque Box Coupe/Fastback R/H 67-70



25-76-38-19 Torque Box Coupe/Fastback L/H 67-68



25-76-38-19A Torque Box Coupe/Fastback L/H 69-70

MAGNUM MUSTANG - HEATER BOX



25-76-43-9 Heater Box, Plegnum Chamber with Gasket Kit & Clip 69-70

MAGNUM MUSTANG - CHASSIS




25-75-38-14 Front Extension Rail Assembly R/H 65-66

25-75-38-13 Front Extension Rail Assembly L/H 65-66



25-75-81-2 Rear Rail Frame Coupe / Fastback R/H 65-68

25-75-81-1 Rear Rail Frame Coupe / Fastback L/H 65-68



25-75-75-4 Half Floor Panel (all models) R/H 64-70

25-75-75-3 Half Floor Panel (all models) L/H 64-70



25-75-75-0 Full Floor Complete Convertible 64-68



25-75-75-1 Full Floor Complete Coupe/Fastback 65-73




25-75-75-7 Front Floor Support 64-66



25-75-75-9 Floor To Firewall Support Convertible (Pair) 65-68



25-77-75-7 Front Floor Support (Pair) 67-68



25-77-75-9 Floor To Firewall Support (Pair) 65-68



25-78-75-9 Floor To Firewall Support (Pair) 69-70

MAGNUM MUSTANG - SEAT SUPPORTS



25-75-74-0 Seat Support Platform Convertible 64-70



25-75-74-3 Seat Support Platform Coupe/Fastback 64-70



25-75-76-4 Seat Support Platform R/H 67-68

25-75-76-3 Seat Support Platform L/H 67-68




25-75-76-0 Rear Seat Mount Panel Convertible 64-66




25-78-76-02 Seat Platform R/H 69-70

25-78-76-01 Seat Platform L/H 69-70



25-79-10-8 Seat Track Assembly (PR) 64-68

MAGNUM MUSTANG - REAR 1/4 PANELS



25-75-51-2 Rear Quarter Panel Fastback R/H 64-66

25-75-51-1 Rear Quarter Panel Fastback L/H 64-66



25-75-51-4 Rear Quarter Panel Convertible R/H 64-66

25-75-51-3 Rear Quarter Panel Convertible L/H 64-66

MAGNUM MUSTANG - REAR 1/4 PANELS



25-76-51-2 Rear Quarter Panel Fastback R/H 67

25-76-51-1 Rear Quarter Panel Fastback L/H 67



25-77-51-2 Quarter Panel W/Early Maker Fastback R/H 68

25-77-51-1 Quarter Panel W/Early Maker Fastback L/H 68



25-78-51-02 Quarter Panel F/B R/H 69

25-78-51-01 Quarter Panel F/B L/H 69



25-78-51-2 Rear Quarter Panel R/H Fastback to 70

25-78-51-1 Rear Quarter Panel L/H Fastback to 70

MAGNUM MUSTANG - REAR SCUTTLE PANEL



25-75-32-0 Rear Bulkhead/Scuttle Panel Convertible 64-66



25-75-32-1 Rear Bulkhead/Scuttle Panel Fastback 64-66



25-75-32-2 Rear Bulkhead/Scuttle Panel Coupe 65-66



25-76-32-0 Rear Bulkhead/Scuttle Panel Convertible 67-68

MAGNUM MUSTANG - REAR SCUTTLE PANEL



25-76-32-1 Rear Bulkhead/Scuttle Panel Coupe 67-68



25-76-32-2 Rear Bulkhead/Scuttle Panel Fastback 67-68



25-77-32-0 Rear Bulkhead/Scuttle Panel Fastback 69-70

MAGNUM MUSTANG - ROOF



25-75-19-0 Roof Brace Rear Fastback 64-66



25-76-19-1 Roof Drip Rail (PR) Fastback 67-68



25-79-10-13 Dash Pad 69-70



25-79-10-5 Dash Panel Trim R/H 67-68



25-79-10-1 Glove Box Door 67-68

MAGNUM MUSTANG - BOOTLID



25-75-70-0 Boot Lid Fastback 64-66



25-75-70-2 Boot Lid Coupe/Convertible 64-66




25-76-70-0 Boot Lid Fastback 67-68



25-76-70-1 Boot Lid Coupe/Convertible 67-68

MAGNUM MUSTANG - BOOTLID



25-78-70-1 Boot Lid Fastback 69-70

25-75-10-14 Boot Lid Hinge Torsion Rods Coupe 67-68

MAGNUM MUSTANG - COWL PANEL / UPPER BULKHEAD / SCUTTLE



25-75-32-3 Front Bulkhead/Scuttle Complete 64-66

25-76-32-3 Front Bulkhead/Scuttle Grille 67-68



25-76-32-4 Front Bulkhead/Scuttle Complete 67-68

25-78-32-0 Front Bulkhead/Scuttle Complete 69-70



25-75-20-3 Radiator Support 65-66



25-76-20-3 Radiator Support 67-68



25-75-20-6 Radiator Support Bracket Lower R/H 64-66

25-75-20-5 Radiator Support Bracket Lower L/H 64-66



25-76-20-6 Radiator Support Bracket R/H 67-70

25-76-20-5 Radiator Support Bracket L/H 67-70



25-78-20-3 Radiator Support 69



25-79-20-0 Radiator Support Panel 71-75



25-79-20-1 Radiator Support Panel 70



25-76-23-01 Grille Support Lower Bar

MAGNUM MUSTANG - REAR FIREWALL / FOLD DOWN SEAT




BACK VIEW

25-75-70-1 Trap Door Behind Rear Seat Fastback 65-66



25-76-30-0 Trap Door Hinge (PR) 65-66



25-76-70-2 Trap Door Behind Rear Seat Fastback 67-68



25-76-70-10 Fold Down Seat Assembly F/B 67-70



25-79-10-9B Fold Down Seat Latch R/H

25-79-10-9A Fold Down Seat Latch L/H



25-79-10-15 Fold Down Seat Moulding Kit Fastback

MAGNUM MUSTANG - BOOT INNER



25-75-88-0 Boot Floor Complete Convertible 64-66



25-75-88-1 Boot Floor Complete Coupe/Fastback 64-66



25-75-88-6 Boot Drop Off R/H

25-75-88-5 Boot Drop Off L/H



25-75-98-0 Tail Lamp Panel Brace Coupe/Fastback 65-68



25-76-65-8 Transition Panel W/Shock Mount 65-70



25-76-88-0 Boot Floor Complete Convertible 65-70
(No Bumper Brackets)



25-76-88-1 Boot Floor Coupe/Fastback 67-68
(No Bumper Brackets)



25-76-30-1 Boot Lid Prop Assembly



25-75-55-2 Rear Wheel Housing Complete R/H 64-66

25-75-55-1 Rear Wheel Housing Complete L/H 64-66



25-75-55-4 Rear Wheel Housing Complete Convertible R/H 64-66

25-75-55-3 Rear Wheel Housing Complete Convertible L/H 64-66



25-75-55-6 Inner Rear Wheel Arch Section R/H 64-66

25-75-55-5 Inner Rear Wheel Arch Section L/H 64-66



25-75-55-8 Inner Rear Wheel Housing R/H 64-70

25-75-55-7 Inner Rear Wheel Housing L/H 64-70



25-76-55-2 Rear Wheel Housing Complete R/H 67-68

25-76-55-1 Rear Wheel Housing Complete L/H 67-68



25-76-55-4 Rear Wheel Housing Complete Convertible R/H 67-68

25-76-55-3 Rear Wheel Housing Complete Convertible L/H 67-68



25-76-55-6 Inner Rear Wheel Arch Section R/H 67-68

25-76-55-5 Inner Rear Wheel Arch Section L/H 67-68




25-78-55-4 Rear Wheel House Outer R/H 69-70

25-78-55-3 Rear Wheel House Outer L/H 69-70



25-75-65-0 Rear Tail Light Panel 65-66



25-76-65-0 Rear Tail Light Panel 67-68



25-76-65-2 Rear Tail Light Panel Shelby 67



25-77-65-0 Rear Tail Light Panel Shelby 68



25-77-65-5 Rear Tail Light Panel 69 (Modify for Shelby)



25-79-65-0 Rear Tail Light Panel 70



25-75-65-10 Boot Corner Panels Fastback R/H 64-66

25-75-65-9 Boot Corner Panels Fastback L/H 64-66



25-75-65-12 Boot Corner Panels Coupe R/H 64-66

25-75-65-11 Boot Corner Panels Coupe L/H 64-66



25-76-65-10 Boot Corner Panels Fastback R/H 67-68

25-76-65-9 Boot Corner Panels Fastback L/H 67-68



25-76-65-12 Boot Corner Panels Coupe R/H 67-68

25-76-65-11 Boot Corner Panels Coupe L/H 67-68



25-75-68-0 Rear Valance (No Reversing Light Hole) 64-66



25-75-68-1 Rear Valance (With Reversing Light Hole) 64-66



25-75-68-2 Rear Valance GT (With Exhaust Holes No Reversing Light Hole) 64-66



25-75-68-3 Rear Valance GT (With Exhaust Holes & Reversing Light Hole) 64-66



25-76-68-0 Rear Valance Standard 67-68



25-76-65-1 Rear Valance W/Dual Exhaust 67-68



25-76-68-1 Rear Valance GT (With Dual Exhaust Hole Cut Outs) 67-68



25-79-68-0 Rear Valance Standard 69-70



25-75-65-5 Rear Light Housing 64-66



25-76-65-5 Rear Lamp Housing 67-68



25-77-98-5 Tail Lamp Bezel 3pc. Set

MAGNUM MUSTANG - DOORS - DOOR SKINS & DOOR PILLARS




25-75-12-2 Door Shell R/H 64-66

25-75-12-1 Door Shell L/H 64-66



25-76-12-2 Door Shell R/H 67-68

25-76-12-1 Door Shell L/H 67-68



25-78-12-2 Door Shell R/H 69-70

25-78-12-1 Door Shell L/H 69-70



25-75-11-2 Door Skin R/H 65-66

25-75-11-1 Door Skin L/H 65-66



25-76-11-2 Door Skin R/H 67-68

25-76-11-1 Door Skin L/H 67-68



25-76-11-8 Door Window Frame Kit Convertible R/H

25-76-11-7 Door Window Frame Kit Convertible L/H

MAGNUM MUSTANG - DOORS - DOORSKINS & DOOR PILLARS



25-78-11-2 Door Skin R/H 69-70

25-78-11-1 Door Skin L/H 69-70



25-76-11-9 Door Sash Escutcheon Stainless (PR)



25-75-40-2/1 A Pillar (Pair) 64-66



25-76-40-2/1 A Pillar (Pair) 67-68



25-75-40-2A/1A B Pillar (Pair) 64-66



25-76-40-2A/1A B Pillar (Pair) 67-68

MAGNUM MUSTANG - FRONT VALANCE



25-75-22-0 Front Valance 64-66



25-76-22-0 Front Valance 67-68



25-79-22-0 Front Valance 69




25-79-22-1 Front Valance 70




25-75-00-2 Front Sill Panel R/H 64-68

25-75-00-1 Front Sill Panel L/H 64-68



25-75-00-4 Sill Convertible Complete with Inner Sill Reinforcement R/H 64-68

25-75-00-3 Sill Convertible Complete with Inner Sill Reinforcement L/H 64-68



25-75-00-6 Sill Coupe/Fastback Complete R/H 65-66

25-75-00-5 Sill Coupe/Fastback Complete L/H 65-66



25-75-00-8 Outer Sill R/H 64-66

25-75-00-7 Outer Sill L/H 64-66



25-76-00-2 Sill (Rocker) Complete Coupe/Fastback R/H 67-68

25-76-00-1 Sill (Rocker) Complete Coupe/Fastback L/H 67-68



25-76-00-6 Outer Sill R/H 67-70

25-76-00-5 Outer Sill L/H 67-70



25-76-06-2 Inner Sill Panel R/H 64-70

25-76-06-1 Inner Sill Panel L/H 64-70



25-76-06-4 Inner Sill Convertible R/H 64-68

25-76-06-3 Inner Sill Convertible L/H 64-68



25-75-90-0 Front Bumper 64-66



25-75-95-0 Rear Bumper 64-66



25-76-90-0 Front Bumper 67-68



25-76-95-0 Rear Bumper 67-68



25-78-90-0 Front Bumper 69-70



25-78-95-0 Rear Bumper 69-70



25-75-22-1 Front Bumper Support Filler 64-66



25-76-22-2 Front Bumper Support Filler 67-68



25-75-90-4/3 Front Bumper (Guard) Overider (Pair) 64-66



25-75-95-4/3 Rear Bumper (Guard) Overider (Pair) Painted 64-66



25-75-95-6/5 Rear Bumper (Guard) Overider Bracket (Pair) 65-66



25-75-95-7/8 Rear Bumper (Guard) Overider (Pair) Chrome 64-66



25-76-95-4/3 Rear Bumper (Guard) Overider (Pair) Chrome 67-68



25-76-90-4/3 Front Bumper (Guard) Overider (Pair) Chrome 67-68



25-75-90-8 Front Bumper Bracket from Bumper to Wing R/H 64-66

25-75-90-7 Front Bumper Bracket from Bumper to Wing L/H 64-66



25-75-90-10 Front Bumper Bracket R/H 65-66

25-75-90-9 Front Bumper Bracket L/H 65-66



25-75-90-12 Front Bumper Inner Bracket R/H 65-66

25-75-90-11 Front Bumper Inner Bracket L/H 65-66



25-75-95-9 Rear Bumper Brackets (Pair) 65-66



25-76-90-8 Front Bumper Bracket Inner R/H 67-68

25-76-90-7 Front Bumper Bracket Inner L/H 67-68



25-76-90-10 Front Bumper Bracket Front Outer R/H 67-68

25-76-90-9 Front Bumper Bracket Front Outer L/H 67-68



25-77-90-8 Bumper Bracket Inner Front R/H 69-70

25-77-90-7 Bumper Bracket Inner Front L/H 69-70



25-76-95-7 Rear Bumper Bracket (Pair) 69-70



25-76-95-8 Rear Bumper Brackets (Pair) 67-68



25-75-88-9 Bumper Bracket in Boot (Pair) 65-66



25-76-88-9 Bumper Bracket in Boot (Pair) 67-68



25-77-88-9 Bumper Bracket in Boot (Pair) 69-70



25-79-10-6 Deluxe Bumper Bolt Kit 64-70



25-79-10-0 Ignition Switch Bracket 67-68




25-79-10-2 Wiper Motor Transmission Arm 66 Only



25-79-10-3 Brake Pedal Automatic 67-68



25-79-10-4 Brake/Clutch Pedal Manual 67-68



25-79-10-7 Front Seats Bottom Spring 65-70

**ALL
BODYSHELLS
MADE TO
ORDER**



MS65CV Body Shell Convertible 65-66



MS65FB Body Shell Fastback 65-66



MS67FB Body Shell Fastback 67-68

**ALL
BODYSHELLS
MADE TO
ORDER**



MS68FB Body Shell Fastback 68



MS69FB Body Shell Fastback 69



MS70FB Body Shell Fastback 70

MUSTANG SPECIALISTS

ARTTUS	LINCOLNSHIRE	01427 788910	www.midnightclassicpanels.co.uk
AVOLUTION MOTORSPORT	DERBYSHIRE	07875 209231	
BILL SHEPHERD MUSTANG	SURREY	01932 340888	www.billshepherdmustang.com
CAR-BODY-PANELS	DOREST	01202 399224	www.car-body-panels.com
CHILIMOTO SPEED SHOP	YORKSHIRE	07789 110721	www.chilimoto.com
CLASSIC AMERICAN RESTORATION	ESSEX	01992 890969	www.totalmustang.co.uk
DIRECT PANELS	GLASGOW	0141 3323335	www.directpanels.co.uk
ESSEX MUSTANG CENTRE	ESSEX	01702 820033	www.essexmustang.com
MC TRADING	KENT	01732 742881	www.classiccarpanelsdirect.co.uk
MOUNT PANELS	LEEDS	0113 236 0360	www.mountpanelsleeds.co.uk
MUSTANG WORKSHOP	HAMPSHIRE	01256 761991	www.mustangworkshop.co.uk
SD DEVELOPMENTS	LANCASHIRE	07879 043941	sddevelopments@btconnect.com
WEST MIDLAND AMERICAN VEHICLE	WOLVERHAMPTON	01902 798840	www.american-vehicles.com

MUSTANG SPECIALISTS (OVERSEAS)

PASSION AUTO FRANCE.com	FRANCE	09 70 70 70 05	www.passionautofrance.com
RS PRODUKTER AB	SWEDEN	0046 705 332600	www.escortmarkone.com
US-PART-FINN-AM OY	FINLAND	0035 892 5131980	harri.karvonen@usparts.fi



MAGNUM CAR PANELS LTD

Lawton Street Rochdale
Lancashire England OL12 0LQ
Tel: +44(0)1706 359666
Fax: +44(0)1706 342704
Email: sales@magnumcarpanels.co.uk

www.magnumclassicmustangpanels.co.uk



Find us on facebook at www.facebook.com/magnumclassiccarpanels